

Installation instructions



Frame is supplied with an MDF blank panel fitted to keep the frame rigid. The frame should be bedded in place to finished floor level, ensure the frame is fully supported around the full perimeter. The frame should then be tiled around to fully secure before the lid is fitted.



Once the frame is tiled around the MDF blank can be removed and disposed of along with the bolts fixing this. The lid should then be bolted in position prior to tiling the lid to ensure the lid is perfectly flat.



Screw the lifting eyes into the threaded fittings within the bolt holes and lower the lid into place. Remove the lifting eyes, apply a small amount of the oil supplied onto the bolts before bolting the lid down.



Using flexible tile adhesive, tile the lid to complete the installation. Store lifting key box in a safe place for end user.